
BEFORE YOU BEGIN

Fill & start the jacuzzi

IMPORTANT: DO NOT SET THE TEMPERATURE UNTIL THE TUB IS FULL

1 Fill the tub

FILL BUTTON



1. Check that all control-panel lights are off. Press any lit button to turn it off.

2. Press Fill to start filling.

3. After about 20 minutes, press Fill to pause and reset the hot-water heater. It may flash “EN”.

4. Wait 10 seconds, then press Fill again. Filling stops automatically at the proper level.

WAIT UNTIL THE TUB IS FULL

Do not set the temperature while the tub is filling. The tub can spray water if the controls are set before it is full.

2 Turn on heat & circulation

POWER / TEMPERATURE



Only when the tub is full:

Press the center power / temperature control to turn on the jacuzzi. The water will circulate and heat continuously.

Use the ▲ and ▼ buttons to adjust the temperature. Suggested setting: 36 °C (97 °F).

WHILE USING THE JACUZZI

Jets, lights & draining

Use the lower jet button shown here. Turn off the jets when you finish using the tub.

3 Jets & lights

LOWER BUTTON = JETS LIGHTS



Jets: Press the lower-left jet button, circled in yellow. Press it again to turn the jets off when you are done.

Lights: Press the sun-symbol button, circled in blue, to control the lights.

Before draining, make sure both jets and lights are off.

4 Turn off & drain

DRAIN BUTTON



1. Turn off the jets and lights.

2. Use ▲ and ▼ to cycle the temperature past 40 until the temperature display turns off.

3. Press the Drain button three times, following the display sequence below. The power turns off and the tub drains.

DRAIN DISPLAY SEQUENCE

UA Press Drain › **Yn** Press again › **UA** Press once more

IMPORTANT REMINDER

When not using the jacuzzi

1 TURN OFF THE JETS

Press the lower-left jet button again to switch them off.



JET BUTTON

The lower-left button is circled in yellow.

2 LOWER THE TEMPERATURE

Use the temperature controls to reduce the setting when you are not using the jacuzzi.

JETS OFF • TEMPERATURE LOWERED

Thank you for helping us care for the jacuzzi.

DAILY AUTOMATIC RESET

Jacuzzi resets at 5:00 AM

This happens automatically every day.

5:00 AM • EVERY DAY

After the reset:

1. **Top off the water**
   Bring the water back to the proper level.

2. **Reset the temperature**
   Select your desired water temperature again.

IMPORTANT

Make sure the water is at the proper level before setting the temperature or starting the jets.